

Installation Instructions

For FITOK Tube Fittings Over 1 in. or 25mm O.D.

Steps:

1. Preset the ferrules onto the tubing using the FITOK Hydraulic Presetting Tool (HPT) referring to the HPT Instructions.
2. Apply the enclosed lubricant sparingly to the thread of FITOK tube fitting body and the rear surface of the back ferrule.
3. Install the preset assembly (tubing, nut, front and back ferrules) into the fitting body. Finger tight the nut. Further tighten the nut 1/2 turn with a wrench while holding the fitting body steady.

FITOK

FITOK Group

FITOK GmbH

Spredlinger Landstr. 115, 63069 Offenbach am Main, Germany
Tel.: +49 69 8900 4498 Fax: +49 69 8900 4495

FITOK, Inc.

13843 North Promenade Blvd., Suite 750, Stafford, Texas 77477, USA
Tel.: +1 281 888 0077 Fax: +1 281 582 4051

FITOK (Wuhan) Incorporated

Zhongbai Yangluo Industrial Park, Hanshi Road, Xinzhou District, Wuhan, Hubei Province, 430415, China
Tel.: +86 27 8983 8988 Fax: +86 27 8983 8980

FITOK (Shenzhen) Incorporated

No.164 Xinqu Village, Tiantou Community, Shijing Street, Pingshan District, Shenzhen 518118, China
Tel.: +86 755 2803 2500 Fax: +86 755 2803 2619

FITOK (Suzhou) Metal Products Co., Ltd.

No. 29 Changsheng Road, Yangyuan Industrial Park, Xinzhuang Town, Changshu, Jiangsu 215562, China
Tel.: +86 512 5247 9001 Fax: +86 512 5247 9002

FITOK Middle East Oil Equipment Trading LLC

Makateb Building, P.O. Box 185412, Airport Road, Deira, Dubai, UAE
Tel.: +971 4 2959 853 Fax: +971 4 2959 854

info@fitokgroup.com
www.fitokgroup.com

